



# METAL FLOORING

## INSTALLATION RECOMMENDATIONS

- Keep flooring at room temperature 24 hours prior to installation
- Clean underside of material with lacquer thinner
- Ensure substrate is flat; free of nails/screws, dirt, debris, grease
- Use a miter saw with a non-ferrous blade for a clean square cut
- Cut slowly - do not force blade through material to prevent burring
- Soften cut edges with steel wool or scouring pad
- Apply a generous bead of adhesive to back of material
- Set flooring firmly in adhesive by pressing down on flooring
- Keep weight on material to ensure proper adhesion
- Clean excess adhesive with lacquer thinner
- Wait at least 24 hours before use

## TOOLS REQUIRED FOR INSTALLATION

- Miter saw
- Non-ferrous metal saw blade
- Steel wool or scouring pad
- Lacquer thinner
- Caulk gun
- Recommended adhesive: Loctite Pro Line 3x Premium Construction Adhesive

## MAINTENANCE RECOMMENDATIONS

To care for SA Baxter metal flooring, regularly apply a wax polish such as Renaissance Wax. Buff out individual scratches or areas of concern using a wet, medium-grade scouring pad. To restore large areas of flooring a professional full wet sand is recommended. Note that all sanding is to be done using a light surface orbital sander.



NEW YORK  
(800) 407-4295

[SABAXTER.COM](http://SABAXTER.COM)

LONDON  
+44 (0) 20-8196-2410